6.Particles2	
'ednesday, April 17, 2013	
26 PM	
Last time: Particle generation in air: Smoke	
Today:	
Fog	
Particle gen in water	
) Fog = aerosols of liquids	
rog – aerosois or liquius	
/ater fog: Safe, but evaporates quickly	
 ultrasonic humidifier http://www.youtube.com/watch? 	• • • •
v=rN-OcMSwS2I&feature=youtube_gdata_player	sonication
 <u>http://www.youtube.com/watch?</u> 	
v=rkrLI7tJOIg&feature=youtube gdata player with	
acoustic streaming	ACOUSTIC STREAMING
medical nebulizer device (colid CO2)	STREAMING
dry ice (solid CO2)	transducer = diaphragm
	vibrates @ n MHz
Check of the local division of the local div	
	Matt Blessinger
	Get Wet 2009
Bernoulli atomiz	
Jet nebulizer	
Small Volume Ne	ebulizer (SMN)
$\overline{\mathbf{C}}$	
	Inexpensive: \$3
	Makes 1 µm to 100µm droplets
	Makes 1 µm to 100µm droplets
	Makes 1 µm to 100µm droplets
	Makes 1 µm to 100µm droplets
	Makes 1 µm to 100µm droplets
<i>7</i> 6	Makes 1 µm to 100µm droplets
Top fits citizer a	Makes 1 μm to 100μm droplets Larger droplets impact on surfaces, can't exit device.
Top fits etiter a ere or an aerosol made Easy assembly difusescently with revel-one cap provides a the revel-one cap provides a	Makes 1 µm to 100µm droplets
Top fits cliner a ter or an across made Easy acrossity (disassembly)	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits etiter a ter or an aerosol mask Earry assembly difusesembly telsh screas-on cap provides a cak-preof seal Cons design provides more room for earry, tionreage for elawing Consider surface area	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits cifier a nead: Eary assembly disassembly with screw-on cap provide a leak-proof seal Consider surface area croates surface area croates maximum. Allows	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits citier a ter or an acrosol made Easy assembly of tissesembly with screas-one cap provides a inde-proof seal Cone design provides inde-proof seal Cone design provides inde-proof seal Cone design provides Scalioped cuff provides sability	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits citier a te or an acrosol made Easy assembly disassembly with screas-on cap provides a cab-proof seel Creasier surface area creasier maximum captilary action. Allows operation at any angle	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits cifier a ten or an acrosol mask Eary assembly (fituessembly teth screw-on cap provides a cal-proof seal Creater surface area creaters maximum copilary action, filous	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits cities a mask Europ assembly (Stassembly with screar-on cap provides a call-proof seal Creater surface area copilary action. Allows operation at any angle	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits criter a and Top fits criter a made Early assembly diffusescently with a rear-one cap provides a lad-proof seat Creatier surface area copillary action. Allows operation at any angle Compression at any angle	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits citier a act or an acrossol made Easy assembly difusesembly with screar-on cap provides a cade-preof seal Creater surface area coptilary action. Allows operation at any angle	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits etiter a ter or an aerosol madi Eary assembly diffusescently with a rear-one cap provides a cad-proof seat Creater samface area copillary action. Allows operation at any angle CompRESSED A IR	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fits citizer a tex or an aerosol made Early assembly diffusescently telebar y assembly diffusescently telebar y assembly diffusescently telebar y and for a say, terror cash provides a container sanyface area creaters maximum copillary action, Aliceus operation at any angle OR Supply.com	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fils citizer a and Top fils citizer a ter or an aerosol made Dery assembly diffusescendby teleb screar-on cap provides a lask-proof seal Creatier samface area creaters matchman capillary action. Allows operation at any angle OR Supply.com	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fils citizer a and Top fils citizer a ter or an aerosol made Dery assembly diffusescendby teleb screar-on cap provides a lask-proof seal Creatier samface area creaters matchman capillary action. Allows operation at any angle OR Supply.com	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fils citizer a and Top fils citizer a ter or an aerosol made Dery assembly diffusescendby teleb screar-on cap provides a lask-proof seal Creatier samface area creaters matchman capillary action. Allows operation at any angle OR Supply.com	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fils retions a acrossol mask Every assembly diffusescently with across-new cap provides a lask-proof seal lask-proof seal carbon coperations at any angle Creater samplace area coperations at any angle Constructions and account of the samplace area coperations at any angle Constructions and account of the samplace area coperations at any angle Constructions and account of the samplace area coperations at any angle Constructions and account of the samplace area coperations at any angle Constructions and account of the samplace area coperations at any angle Constructions and any angle Constructions and account of the samplace area coperations at any angle Constructions and any angle Constructions and any angle Constructions at any angle	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fils relier a are or an arroad Bary assembly diffusionably barb systembly barb systembly barb systembly barb systembly creater satiface area creater satiface area creater maximum complex data construction at any angle Compressed D ATR OR Supply.com Dry Ice Vapor: Dry ice = solid CO2 Sublimates (solid to gas) at 1 atm, -78 C (-109 F) http://www.dryiceinfo.com/fog.htm Submerge in hot water: much water fog created. Fog production drops for water temperature < 50 F	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.
Top fils relier a are or an arroad Bary assembly diffusionably barb systembly barb systembly barb systembly barb systembly creater satiface area creater satiface area creater maximum complex data construction at any angle Compressed D ATR OR Supply.com Dry Ice Vapor: Dry ice = solid CO2 Sublimates (solid to gas) at 1 atm, -78 C (-109 F) http://www.dryiceinfo.com/fog.htm Submerge in hot water: much water fog created. Fog production drops for water temperature < 50 F	Makes 1 µm to 100µm droplets Larger droplets impact on surfaces, can't exit device.

Stage fog = Water + glycerin or propylene glycol. Additive slows evaporation



Small machines: heater too small to run continuously. Buy at Target, 1 month before Halloween for \$25. Large machines: can run continuously. For professional stage and theaters. \$1000. Mfg: Roscoe, Le Maitre. 1 gallon lasts 4 hrs.

Health effects are minimal, except to asthmatics and opera singers.



For fog-on-the-ground: chillers

C) Oil aerosols

Won't evaporate unless burned. Oil has low vapor pressure. Use medical or Bernoulli atomizer/nebulizer

Can be used to mark flame fronts. Illuminate fog with a laser sheet = "laser tomography" in 1980s.



Tomographic Study of a Laminar Flame In a Karman Vortex Street." Combustion Science and Technology 38 (1984): 205-216.



FIGURE 1 Experimental apparatus. The bright region is a cloud of oil droplets illuminated by the laser.





FIGURE 6 Example of tomography with combustion; from high-speed 16 mm film. The flame appears as the boundary of the dark V-shaped region. One complete cycle of interaction with vortex street is shown.

D) Dusts

AlO₂ = alumina, aluminum dioxide. Polishing powder, available in submicron diameters. Inexpensive. Won't burn; is already fully oxidized. Good for imaging individual particles in flames. Aerosolize in a cyclone seeder:



air injected below

Particle Generation in Water

Hydrogen bubbles		0.0	
Electrolytic precipitation		- sol has	
Latex bubbles		Pine Sol Mus	
Pearl Ex	Pine pollen	wax bendo	
Corn starch (diluted)	Rust (filtered)	No. A	
Glass or polystyrene microspheres	Alumina		
Glass of polystylelle microspheres			

Want neutral buoyancy, but for very small particles viscous forces are high. Can use up to 100 μm particles. Good scatterers.

17562671			
4 4 4 5 3 5 3			
1 2 3 6 4 3 2			
154. Orrowth of material lines in isotropic nutrilense. were Periodic cherrical poless generate double lines of			
154. Oversk of samrål lane is isområr andra hubbarase. Aftar ju fartism sin är atte de ist merdela soms verse i varbenda soms verse i varbar hubbara hubbaras. I man i Branch kuppt hubbar i studivkarsegrenering: grif. The Sprachka navlen i Studiosel og spir redisas.			
A CALLE			
155. Wrinkling of a flaid serface in isotropic traditions. Here the platters with generating community. Since of the platters with generating a community. Since of the platters with the platters with the best of the put. The brings mutuation. It is a best of the put. The brings mutuation. M. S. E. data, Also Teplate U. A. 2008.			
deferred by the name starting and the starting of the starting			
m. Henquight by M. J. Karvatt, M. S. E. deen, Abba Hipdara Univ, 1984			
en an			
CAN LE LERE			
and the second sec			
And the has the	Van Dukala Album of Fluid Mation		
30	Van Dyke's Album of Fluid Motion		
Undragen Dubbles			
Hydrogen Bubbles			
min be man	\sim		
3 ft max			
O2 bubbles	-		
H2 bubbles cathode			
anode			
large plate or			
pipe			
pipe at			
•			
Smallest H2 hubbles if wire is very thin Bubbles =	1/2 to 1 wire diameter		
Smallest H2 bubbles if wire is very thin. Bubbles = 1/2 to 1 wire diameter = 25 to 50 μm			
Want small enough bubbles to track flow, and have a slow rise time, so			
< 100 µm needed.			
Best if wire is platinum. Other wires oxidize, and d	on't provide a clean		
sheet of bubbles.			
Minute paper: Why not use O2?			

For same current, get half as much O₂ diffusivity relative solubility surface tension

Need 50 - 70 VDC, 1 amp minimum. For long wires (200 mm) need 250 V, 2 amps Expensive power supply.

The water must conduct well. Add salt. Some refs say sodium sulfate is better than sodium chloride, table salt. Weak acid or base would also conduct, but may eat wire.

Too much salt = bigger bubbles

Probe. Insulate

Pt wire, tight and smooth. Big bubbles form at kinks.

Any ions in the water are attracted to the electrodes, so material plates onto the electrodes, fouls the wire. "Cleaning" = Reverse polarity briefly now and then for a few seconds

Electrolytic Precipitation Technique

•

Same circuitry as H2 bubbles, but 10VDC, 10 mA. Much more reasonable requirements but.... Tracer is electrolytically precipitated oxide at anode, of anode material. Metal often used = solder = tin+lead. Two heavy metals you don't want to put down the drain; needs 5 um filter.







95. Käemän vortes street behind a circu eyilinder at R=200. This bhotograph, ma using a different fluid (and in another ocunt langens to have been timed so as to restrat remarkalsh the flow parters in the upper p ture. A thin sheet of tobacco encole is troduced upstream in a low-extravelyace wit tronduced lysterem in a low-extravelyace wit tanned. Photograph by Gary Koopeasan

Latex Microbubbles.

If too dense, can be 'cooked' to expand to neutral buoyancy

Very expensive! \$100 for a few grams worth.

Molecular Tagging Velocimetry



Can be quantified to measure velocity field.

Dye is molecular, no seed problems.

http://www.egr.msu.edu/tmual/MTV.html

Index of Refraction Techniques

Requires no seed. Can visualize differences and gradients in temperature and chemical concentration, as both change the index of refraction of the media. Techniques discussed in detail: schlieren and shadowgraphy

Color schlieren



Pasted from <<u>http://www.compadre.org/informal/images/features/schlierenlarge-11-29-06.jpg</u>>

A. DAVIDHAZY,

RIT = Rochester Institute of Technology, offers engineering and BS through PhD in Imaging Science.

SHADOWGRAPH



t = 2.14 ms, v = 11.1 ft/s



t=3.22 ms, v=16.9 ft/s



t = 4.30 ms, v = 21.0 ft/s



t = 6.53 ms, v = 24.0 ft/s

81. Growth of vortices on an accelerated plate. Spark shadowgraphs show the history of a 3-inch-square plate in air, accelerated from rest to 24 ft/s. The sharp edge of the plate is initially opposite the first of a series of pins spaced 1/4 inch apart. The motion is actually vertical, and the flow is visualized by painting a narrow band of benzene across the center of the balsa-wood plate, so that when the plate



accelerates benzene vapor is drawn into the vortex sheet. The difference in density between the vapor and the air makes the paths of their boundaries visible. Care was taken to ensure that the undulations observed in the vortex sheet were not caused by vibrations of the model. Pierce 1961



167. Subsonic jet becoming turbulent. A jet of air from a nozzle of 5-cm diameter flows into ambient air at a speed of 12 m/s. The laminar interface becomes unstable as in

figure 102, and the entire jet eventually becomes turbulent. Bradshaw, Ferriss & Johnson 1964



168. Supersonic jet becoming turbulent. At a Mach number of 1.8 a slightly over-expanded round jet of air adjusts to the ambient air through a succession of oblique

and normal shock waves. The diamond-shaped pattern persists after the jet is turbulent. *Oertel 1975*

98



Pasted from <<u>http://commons.wikimedia.org/wiki/File:Schlieren photograph of T-38 shock waves.jpg</u>>

Mach 1.1, full size T-38 in flight, 1993. L. Weinstein, NASA example of Background Oriented Schlieren (BOS). Correlate patterned background from image to get schlieren